

THE RIGGING SHED

LIFTING & RIGGING EQUIPMENT SPECIALISTS

Chain Sling Care and Use

**Safe use of Grade 80 (T) and
Grade 100 (V) Chain Slings**



WANGARA
(08) 9406 9999

BIBRA LAKE
(08) 9494 5800

KALGOORLIE
(08) 9022 8600

PORT HEDLAND
(08) 9406 9999

www.theriggingshed.com.au

info@theriggingshed.com.au

Safe use of Grade 80 (T) and Grade 100 (V) Chain Slings

- Chain slings must only be used in accordance with the SWL's and angles for the configurations specified in AS3775.2 2014. Please refer to the chain tag and applicable load chart.
- All chain slings must be inspected prior to and after each use. Chain slings must also be periodically inspected and recorded by a competent person. Guidance to periodic inspections is included in this document.
- Chain slings must be protected from sharp edges and the appropriate deration applied.
- Ensure chain is free from twists when connected to loads.
- Ensure connections between the chain slings and load are seated and orientated correctly.
- A risk assessment shall be completed for chain slings that will be used in a corrosive environment. Grade 80 (T) and Grade 100 (V) chain slings should not be used in acidic or alkaline environments as this may cause hydrogen embrittlement resulting in failure of the chain sling. The SDS for the solution the chain sling is being exposed to should be consulted.
- Chain slings should be appropriately de-rated for temperature as follows

Temperature Effects for Grade T

Temperature, °C	Reduction of WLL, %
≥ -10 ≥ 200	Nil
> 200 ≥ 300	10
> 300 ≥ 400	25
> 400	Not permissible

Temperature Effects for V400

Temperature, °C	Reduction of WLL, %
≥ -10 ≥ 200	Nil
> 200 ≥ 300	10
> 300 ≥ 380	40
> 380	Not permissible

Temperature Effects for V200

Temperature, °C	Reduction of WLL, %
≥ -10 ≥ 200	Nil
> 200	Not permissible

Storage and Handling.

- Where possible store chains on a properly designed rack.
- Never heat or heat treat chain.
- Lightly oil chain prior to prolonged storage.
- Store chain in dry non-corrosive environments.
- Care must be taken with chain slings that are left on crane hooks to ensure they are not a danger to persons or property and do not become accidentally engaged.
- Avoid dragging chains on hard surfaces

Only persons trained and deemed competent should use this equipment.

A competent person must be able to:

- Assess the mass of the load as accurately as possible.
- Ensure the load will withstand the lifting operation.
- Ensure the lifting appliance is rated to lift the load.
- Select a suitable sling taking into account the following:
 1. The condition of the sling.
 2. The Geometry of the sling including the number of sling legs, the angles of each sling leg.
 3. Each joining device has no more than one load bearing component in use at any one time.
 4. The manner in which the load is attached (i.e straight, reeved or basket configuration). Including the angle in the reeving.
 5. The shape of the load, the centre of gravity and load distribution of the sling.
 6. Determination of the WLL.
 7. Protection of the sling from sharp corners and the use of packing material.
 8. The site where the load is to be landed.
 9. Take into account environmental conditions such as temperature and corrosive atmospheres.
 10. Identify the hazards involved in the task and conduct a risk assessment and control those hazards.

Periodic Inspection.

Periodic recorded inspections performed by a person deemed competent to design, manufacture and inspect chain slings are required.

The recommended periods can be found in the table below but must not exceed 12 months.

The Rigging Shed recommends quarterly inspections for lifting equipment for general frequent use.

Number of lift cycles per week	Inspection monthly	Inspection 3 monthly	Inspection 6 monthly	Inspection 12 monthly
1 to 5	—	—	—	Yes
6 to 25	—	—	Yes	—
26 to 200	—	Yes	—	—
201 plus	Yes	—	—	—

NOTE: The above is a guide and the inspection schedule has to be determined by the end user based on the duty cycle (of M3 as specified in AS 1418.1) and the environmental conditions of use.

Pre and post-use inspection

Ensure tag is present and legible.

Ensure periodic inspections have been completed.

Check master link for elongation, wear, nicks, cuts, gouges, bending or deformation and corrosive pitting.

Check chain connectors for elongation, wear, nicks, cuts, gouges, bending or deformation, corrosive pitting and articulation.

Check chain elongation, wear, nicks, cuts, gouges, bending or deformation and corrosive pitting.








Check hooks, ensure that there is no excessive opening of the hook and the safety catch is fit for use.

Check hooks for elongation, wear, nicks, cuts, gouges, bending or deformation and corrosive pitting.

If damage is suspected please tag the sling out of service and return to The Rigging Shed for inspection, repair and testing.








Grade T/80 Chain Slings

SPECIFICATIONS

Chain Size (mm)	WORKING LOAD LIMIT (TONNES)								
	SINGLE LEG SLINGS				SLINGS OF 2, 3 OR 4 LEGS			2 LEG SLINGS	
									
	Straight or Adj. Sling No Deration	Adj. Sling with Deration	Reeved Sling	Basket Sling Max 60°	60°	90°	120°	Max 60°	Max 60°
Loading factors	1	0.75	0.75	1.3	1.73	1.41	1	1.3	2.25
6	1.1	0.8	0.8	1.5	1.9	1.6	1.1	1.5	2.5
7	1.5	1.1	1.1	2	2.6	2.1	1.5	2	3.4
8	2	1.5	1.5	2.6	3.5	2.8	2	2.6	4.5
10	3.2	2.4	2.4	4.1	5.5	4.5	3.2	4.1	7.2
13	5.3	4.0	4.0	6.9	9.2	7.5	5.3	6.9	11.9
16	8	6.0	6.0	10.4	13.8	11.3	8	10.4	18.0
19	11.2	8.4	8.4	14.6	19.4	15.8	11.2	14.6	25.2
20	12.5	9.4	9.4	16.3	21.6	17.6	12.5	16.3	28.1
22	15	11.3	11.3	19.5	26.0	21.2	15	19.5	33.8
26	21.2	15.9	15.9	27.6	36.7	29.9	21.2	27.6	47.7
32	31.5	23.6	23.6	41	54.5	44.4	31.5	41	70.9

Grade V/100 Chain Slings

SPECIFICATIONS

Chain Size (mm)	WORKING LOAD LIMIT (TONNES)								
	SINGLE LEG SLINGS				SLINGS OF 2, 3 OR 4 LEGS			2 LEG SLINGS	
									
	Straight or Adj. Sling No Deration	Adj. Sling with Deration	Reeved Sling	Basket Sling Max 60°	60°	90°	120°	Max 60°	Max 60°
Loading factors	1	0.75	0.75	1.3	1.73	1.41	1	1.3	2.25
4	0.63	0.5	0.5	0.8	1.1	0.9	0.63	0.8	1.4
5	1	0.8	0.8	1.3	1.7	1.4	1	1.3	2.3
6	1.4	1.1	1.1	1.8	2.4	2.0	1.4	1.8	3.2
7	1.9	1.4	1.4	2.5	3.3	2.7	1.9	2.5	4.3
8	2.5	1.9	1.9	3.3	4.3	3.5	2.5	3.3	5.6
10	4	3.0	3.0	5.2	6.9	5.6	4	5.2	9.0
13	6.7	5.0	5.0	8.7	11.6	9.4	6.7	8.7	15.1
16	10	7.5	7.5	13.0	17.3	14.1	10	13.0	22.5
18	12.5	9.4	9.4	16.3	21.6	17.6	12.5	16.3	28.1
19	14	10.5	10.5	18.2	24.2	19.7	14	18.2	31.5
20	16	12.0	12.0	20.8	27.7	22.6	16	20.8	36.0
22	19	14.3	14.3	24.7	32.9	26.8	19	24.7	42.8
23	21	15.8	15.8	27.3	36.3	29.6	21	27.3	47.3
26	26.5	19.9	19.9	34.5	45.8	37.4	26.5	34.5	59.6
28	31.5	23.6	23.6	41.0	54.5	44.4	31.5	41.0	70.9
32	40	30.0	30.0	52.0	69.2	56.4	40	52.0	90.0



The Rigging Shed provides services in inspecting, repairing and testing chain slings.
The Rigging Shed also offers mobile testing, with our technicians using tablets that update our online database, so you have access to the test results on completion of the test.

THE RIGGING SHED

LIFTING & RIGGING EQUIPMENT SPECIALISTS

FROM ON-SITE TO ON-LINE

Managing your lifting and rigging equipment supply and maintenance requirements

Wangara

53 Prosperity Ave
Wangara WA 6065
ph (08) 9406 9999
fax (08) 9406 9900

Bibra Lake

2/34 Discovery Dve
Bibra Lake WA 6163
ph (08) 9494 5800
fax (08) 9434 1042

Kalgoorlie

25 Darcy Lne
Kalgoorlie WA 6430
ph (08) 9022 8600
fax (08) 9022 8700

Port Hedland

23 Pinnacles Street
Wedgefield WA 6721
ph (08) 9406 9999
fax (08) 9406 9900

www.theriggingshed.com.au | info@theriggingshed.com.au



YOKE GUNNEBO RUD